



Jeep Wrangler YJ SUN TOP

Installation Guidelines

For: 1988-1995 Jeep Wrangler YJ Sun Tops

PN: 10-40-YJS

!!STOP!! Before proceeding make sure the upper door is the correct item for the vehicle you are installing it on.

DO NOT INSTALL THIS ITEM ON ANY VEHICLE OTHER THAN ONE LISTED ABOVE

The material may have contracted, depending on at what temperature it has been stored. It is highly recommended that you remove the upper doors from the box; lay it out flat at a temperature above 72F and let it relax for at least 24 hours. As well the installation should be done only in an environment where the air temp is above 72F.

To avoid improper installation of this item it is imperative that you read and follow these guidelines completely. Failure to install the upper door skins correctly may result in a dangerous situation for the vehicle occupants as well as other motorists.

SIERRA OFFROAD TAKES NO RESPONSIBILITY FOR THE ACCURACY OR COMPLETENESS OF THESE INSTALLATION GUIDELINES. THEY ARE PROVIDED ONLY FOR INFORMATION PURPOSES. IT IS THE SOLE RESPONSIBILITY OF THE INSTALLER TO ENSURE THAT THE INSTALLTION HAS BEEN PERFORMED CORRECTLY, THERE ARE NO LOOSE OR MISSING PARTS AND THE VEHICLE HAS BEEN ROAD TESTED AFTER INSTALLATION OF THE REPLACEMENT TOP AND DEEMED SAFE TO OPERATE.

PARTS LIST

Fabric Sun Top Qty 1

TOOLS REQUIRED

None



THESE UPPER DOORS ARE INTENDED TO BE FIT OVER THE FACTORY ORIGINAL HARDWARE AND FRAME. IF THE FRAME IS DAMAGED OR MISSING PARTS DO NOT ATTEMPT THIS INSTALLATION BEFORE REPAIRS ARE MADE TO THE VEHICLE.

It is important to read the complete instruction guideline manual BEFORE beginning the installation of your new replacement upper doors. This will familiarize you with all aspects of the installation and help to avoid mistakes. It will be helpful if you keep this guideline manual for future reference.

SIERRA OFFROAD
FACTORY REPLACEMENT JEEP SOFT TOPS

1988-1995 Jeep Wrangler YJ SUN TOP Installation



1

Check Your Windshield Channel

Wrangler must have the factory OE style Soft Top windshield channel to install Sun Top



2

Position Top Roll Bars

Position the Sun Top over the roll bars and insert the front edge plastic retainer into the Windshield channel.

1988-1995 Jeep Wrangler YJ SUN TOP Installation

Stretch back the rear edge of the Sun Top over and down the roll bar.



Stretch Rear Edge Over Roll Bar

3

Insert the rear center strap end through the windshield's support bracket.



Insert Rear Center Strap

4

1988-1995 Jeep Wrangler YJ SUN TOP Installation



5

Guide Rear Center Strap Through Buckle

Run the rear center strap end through the buckle and pull to secure in position.



6

Stretch Rear Corners Over Roll Bar

Stretch the rear corners of the Sun Top over and down the roll bar, run the corner straps through the side loops (going forward).

1988-1995 Jeep Wrangler YJ SUN TOP Installation

Run the rear corner straps back through the rear corner loops and secure to the male buckles.



Secure Rear Corner Straps

7

Secure the buckles into each other and pull straps to secure in position.



Secure Buckles Into Each Other

8

1988-1995 Jeep Wrangler YJ SUN TOP Installation



9

Wrap Straps Around Roll Bars

Locate the side Velcro straps, wrap the straps around the roll bars and fasten.



CARE AND MAINTENANCE OF YOUR NEW SUN TOP

Wash vinyl fabric exterior only using a mild soap and a soft brush. Rinse thoroughly.